

6539087




FIG. 1




FIG. 2

300

TRANSFER BUFFERS	302
SYSTEM PARAMETERS	304
DTMF PARAMETERS	306
TALK DETECTION LEVEL	308
GAIN AND POWER FACTORS	310
TONE FREQUENCIES AND SEQUENCES	312
NODE INFORMATION	314
NODE NUMBER	316
NUMBER OF CHANNELS	318
ACTIVE NODES	320
REVISION NUMBER	322
ACKNOWLEDGE	324
SYNC LOST	326
CHARCNT	328
REMOVE BUFFER	330
EVENT BUFFER	332
CHANNEL STRUCTURE (ARRAY)	334
LOGICAL CHANNEL NUMBER	336
SLOT TYPE	338
COMMAND	340
COMMAND DATA	342
TONE LEVEL	344
ERROR	346
TALK	348
CONFERENCE	350
MUTE	352
AUTOMATIC GAIN CONTROL	354
MUSIC	356
BUFFER INDEX	358
DIGITS OUT	360
MAILBOXES	362
DSP MAILBOX	364
HOST MAILBOX	366

FIG. 3

CONFERENCE CHANNEL




FIG. 4




FIG. 5




FIG. 6




FIG. 7